

Quality Hand Crafted Stainless Steel Mailboxes and Accessories

www.grandpas-stainless-workshop.com

INSTRUCTIONS FOR MOUNTING YOUR CURB MAILBOX ON A HORIZONTAL ARM









PLACE BOX ON ARM

MARK MOUNTING HOLES

HOLE MARKINGS

DRILL 9/32" HOLES



1/4" ROUND HEAD SS BOLT AT LEAST 1/4" LONGER THAN ARM THICKNESS



SS WASHER & LOCK NUT



USE BOLTS TO GUIDE MAILBOX PLACEMENT



USE A SCREWDRIVER TO HOLD THE BOLTS IN PLACE



WHILE YOU THREAD THE WASHERS AND LOCK NUTS ON THE END OF THE BOLTS



COMPLETE THE INSTALLATION
BY TIGHTENING THE LOCK NUTS
DOWN WITH A BOX WRENCH